Slammer Tables w/Double Laminated Wood Base Assembly Instructions

Model Number TT217-3650

www.norix.com • TEL 800 234-4900

Or

RNIT

Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List				Tools Needed
ITE	M QTY.	PART NUMBER	DESCRIPTION	Flat Head Screw Driver
Α	. 1	021-003	Machine Screw, 5/16"-18 x 1-3/4", Black Oxide	
В		030-007	Plate, Slammer Kit	
С		030-026	Base, X-Slammer, Bottom, Top Groove	
D		030-027	Base, X-Slammer, Top, Bottom Groove	
E		054-3650	Top, Multi-Base-Pattern, 36"x50", PT, T-Edge, Dbl X-Base	
		•		

Step 1:

Stand the table base with the notch in the unfinished side, so that the flat head screws are up.

Step 2:

Form "X" base by sliding the other table base over the center notch in the first base.

Step 3:

Remove the 16 flat head screws from the table bases.

Step 4:

Place the base plate down over the table base so that there are 16 tapered holes up, and align with the screw holes in the base.

Step 5:

Complete the table base by reinserting the 16 flat head screws through the base plate and into the table base.

Step 6:

Place the table top on a soft protective flat surface with the bottom side up.

Step 7:

Invert the table base and place on the table top aligning the 3 screw holes on each side.

Step 8:

Attach the table base to the table top using 24 tamper-resistant flat head screws. Hand start the screws, and tighten with Torx key provided. (Do not over-tighten as damage may occur to table top.)