



Attenda No Mounting Holes Assembly Instructions

Model Number
ATN103, ATN103B, ATN123, ATN153, ATN133

www.norix.com • TEL 800 234-4900

Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List				Tools Needed
ITEM	QTY.	PART NUMBER	DESCRIPTION	Low RPM Variable Speed Drill
A	14	029-066	Sleeve, 3/4" OD x 5/8" ID x .97"L, Stainless Steel, Attenda Bed Mnt Holes	Drill Bit 1/8"
				Drill Bit 3/8"
				Drill Bit 47/64"
				Caulk

1. Identify what holes you want anchored. (We recommend using all that are reachable)
2. Position bed upside down so you can see the underside of bed.
3. Identify the witness lines in the shape of a circle under each alcove.
4. In the center of the circle, drill a pilot hole using 1/8" drill bit. Enlarge that hole using a 3/8" drill bit. End by using a 47/64" drill bit.
5. Do this for the remaining locations that will be anchored.
6. Insert sleeves into holes.
7. We recommend using caulk around the perimeter of the bed and on top of the drilled locations to ensure a waterproof seal.