



VersaFrame - Boltdown Installation Instructions

Model Number
VFB1-XXX-XXXX
VFB0-XXX-XXXX

www.norix.com • TEL 800 234-4900

Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List				Tools Needed
ITEM	QTY.	PART NUMBER	DESCRIPTION	Low RPM Variable Speed Drill
A	1		VersaFrame Seat(s)	Min. 3/8" Concrete
B	4	024-003	Anchor, Secure Bolt, 3/8" x 2-1/2" L, 5/16-18 Thread, Pin in Torx T-45, SST Post, Zinc Plated	Shop Vacuum
				Hex Driver

STEP 1. Position the VersaFrame Seating Unit in the desired location.

STEP 2. Stabilize the unit by adjusting the bolt-down tabs on each leg. Rotate the tabs clockwise to raise (extend) the legs or counterclockwise to lower (shorten) them.

STEP 3. Once the unit is stable, mark the floor at each leg to indicate where the anchors will be installed. Then, remove the unit from the installation area.

STEP 4. Using a concrete drill bit, drill a 2.5-inch deep hole at each marked location to accommodate the anchors. Clear out all concrete dust from the holes and surrounding area using a vacuum to ensure proper anchor seating.

STEP 5. Return the VersaFrame Seating Unit to its original position, aligning the bolt-down tabs with the drilled holes.

STEP 6. Insert and tighten the anchors to securely fasten the unit in place.

