


Safehouse End Panel Desk Assembly Instructions

Model Number SH6104-1XYZ; SHU6104-1XYZ



Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

<u>Parts List</u>			
ITEM	QTY.	PART NUMBER	DESCRIPTION
Α	1	SH6104-1XYZ	Safehouse End Panel Desk
Α	1	SHU6104-1XYZ	Safehouse End Panel Desk
В	4	029-T004-XX	Bracket, Bolt-Down

Tools Needed
Low RPM Variable Speed Drill
3/8" Concrete Drill Bit
Wall Anchor (2) (optional)
Driver for Anchor

Unit can be anchored to the wall by drilling an appropriately sized hole through the back panel and attaching with suitable hardware.

Unit can be attached to an adjacent unit by drilling through the side panel and using suitable hardware to hold units together.

Unit can be anchored to the floor using the 'L' Bracket. If unit has floor glides, it is recommended that they be removed and discarded for floor anchoring. Drill a hole through the Side Panel and use appropriate hardware to secure the bracket to the panel. Using the holes in the brackets as a guide, mark the hole locations on the floor. Set the unit aside and install appropriate anchors.

