



Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List

ITEM	QTY	PART NUMBER	DESCRIPTION
A	1	050-T100-XX	Titan Panel, Bottom, Enclosure/Sleep Surface
B	14	021-103/021-104	Screw 10-24 X 5/8 L Pan Hd, Sq Skt Hd Cap, Self Drilling (Zinc / Black)

Tools Needed
Variable Speed Drill
#2 Square Driver

STEP 1: Remove (4) Glides.

STEP 2: Align Enclosure Panel (A) within recess on bottom of bed.

STEP 3: Drive screws (B) through holes in panel and into bed vertical panels. Do not over-torque screws.

