

Forté® Lounge Arm Chair with Wood Base

NORIX®

SPECIFICATIONS



Model

FC620/FC680

Weight

44 lbs

*Intended for indoor use only

Dimensions

Seat Height

18.3"

Seat Width

21.9"

Overall Height

32.9"

Depth

30.9"

Width

27"

Arm Height

26.3"

COM Yards

Total Yards

1.15

Stinson
SEE / SAMPLE / SPEC



DETAILS

Color

Seat: Canyon, Wild Berry, Meadow, Mojave, Pine Cone, River Rock, Lagoon, Graphite, Sea Spray.

Base: Teak, Walnut, and Maple colored finish with two part stain and clear coat.

*Due to differences in monitors, printers and materials, actual product colors may vary. Color chips are available for more accurate depiction of color.

Options

Optional upholstered plywood shell comes factory installed and can be easily removed for cleaning or replacement. Cushioned comfort provided by polyurethane foam on back and seat. Upholstered flammability standard upgradeable to TB133.

Ganging Kit, Bolt-Down Kit

Upholstery

View our upholstery selections at www.norix.com/fabrics. Fabric Grade Levels: Grade A, Grade B, Grade C, Grade D, Grade E, Grade F, Grade G, Grade H, COM.

Patents

Patents Pending

Fabrication & Material

Seat: One-piece rotationally-molded polyethylene with lightly textured maintenance free surface allows for easy cleaning. High-impact polyethylene with ultraviolet light stabilizers (to reduce fading). Chemically resistant to blood, vinegar, urine, feces, salt solution and chlorine solution. Premium TruColor™ polymer is fully compounded for superior color consistency and durability.

Base: Glued mortise and tenon. Molded-in steel threaded inserts for optional ganging side-to-side. 3" solid hardwood frame with tapered legs.

Made in the U.S.A.

Assembly

None required

Installation

Required for ganging plates

Warranty

10 year limited replacement warranty

Maintenance

Seats: For routine and regular cleaning maintenance, Norix recommends the use of Simple Green® or an equivalent cleaning product. This product is bleach/water solution cleanable and suitable for use with hospital-grade disinfectants (such as Virex®, Wexcide® or Oxivir Five 16®) per manufacturers' instructions.

Base: For wood products, Norix recommends using a mild wood cleaner for routine and regular cleaning maintenance. For the deep-scrub cleaning of tougher stains, marks and debris, we recommend the use of a regular-strength wood cleaner.

Optional Upholstery: Refer to Upholstery Manufacturer's cleaning instructions.

TESTING

Performance Test Standards

- Tested to 750 lb static load
- Product dynamic drop tested to a relative impact force of two times BIFMA 5.4 15.4.2 (250 lbs from 18")

Environmental Test Standards

- GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG. Plastic is Recyclable #7
- Compliant with Healthier Hospitals guidelines

Flammability Test Standards

Compliant with the following flammability standards:

- Upholstered Chair: State of California, Technical Bulletin No. 117, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- Non-Upholstered Chair: State of California, Technical Bulletin No. 133, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- State of California, Technical Bulletin No. 117, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- UL1056 Fire Test of Upholstered Furniture
- ASTM E1537 Test Method for Fire Testing of Real Scale Upholstered Furniture Items
- NFPA 261 Cigarette Ignition Resistance of Upholstered Furniture
- UL94 HB Test for Flammability of Plastic Materials
- British Standard BS 7176: 2007, High Hazard Occupancy (BS EN 1012-1: 2006, BS EN 1012-2: 2006, BS 5852: 2006)