# Attenda<sup>®</sup> Space-Saver Bed with Storage





| Model  | ATN130            |
|--------|-------------------|
| Weight | 140 lbs / 63.5 kg |

| Bed Dimensions      | in    | cm    |
|---------------------|-------|-------|
| Overall Length      | 78″   | 198.1 |
| Overall Width       | 32″   | 81.3  |
| Height              | 22.6″ | 57.4  |
| Bed Deck Length     | 76″   | 193.1 |
| Bed Deck Width      | 30″   | 76.2  |
| Cubby<br>Dimensions | in    | cm    |
| Cubby Width         | 27″   | 68.6  |
| Cubby Depth         | 18″   | 45.7  |
| Cubby Height        | 15″   | 38.1  |

Note: Dimensional tolerances are +1% due to manufacturing process.

# Mattress Size

30"x75" (76.2x190.5 cm)

## **Finishes**

See Design Guide for finish options.

**Options** 

• Model ATN133: No Mounting Holes

## Assembly

None Required.

\*Intended for indoor use only



## **Fabrication & Material**

Slightly textured maintenance free surface allows for easy cleaning. Rotationally molded, specially formulated, high-impact polyethylene with ultraviolet light stabilizers (to reduce fading). Chemically resistant to blood, vinegar, urine, feces, salt solution and chlorine solution. Ligature resistant design with no internal openings. Premium TruColor™ material is fully compounded for superior color consistency and durability. Unit is filled with rigid polyurethane foam for increased durability and sound absorption. Made in the U.S.A.

#### Warranty

10 year limited replacement warranty.

Norix recommends products placed in storage prior to installation should be held in a climate controlled area similar to the room where the product will be used. Norix also recommends that any Attenda® products shipped via ocean container maintain a temperature of 70-75°F (21.1-23.9°C) with a Relative Humidity of 35%.

#### Maintenance

For routine and regular cleaning maintenance, Norix recommends the use of Simple Green® or an equivalent cleaning product. Attenda® products are bleach/ water solution cleanable and suitable for use with hospital-grade disinfectants (such as Virex®, Wexcide® or Oxivir Five 16®) per manufacturers' instructions. Norix recommends regular monthly inspections of all fasteners. Bolt-down fasteners should be tight with no gaps larger than  $\frac{1}{16}$ " (0.2 cm) between the bottom of the bed and the floor. There should be no visible cracks in the caulk, if applied.

## Installation

Wedge anchors and %" (0.95 cm) bolts required for permanently attaching to floor. Anchors and bolts not supplied by Norix. Groove along underside edge for caulk application (caulk not supplied by Norix).

## Patents

This product may be covered by US Patent Nos. US 8,007,059 B2, US 9,661,933 B2 and US 10,507,150 B2.

## **Performance Test Standards**

• Product tested to 1,000 lbs (453.6 kg) static load.

## **Environmental Test Standards**

• GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG.

## **Flammability Test Standards**

- State of California, Technical Bulletin No. 133, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- State of California, Technical Bulletin No. 117, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- UL1056 Fire Test of Upholstered Furniture
- ASTM E1537 Test Method for Fire Testing of Real Scale Upholstered Furniture Items
- NFPA 261 Cigarette Ignition Resistance of Upholstered Furniture