

## SPECIFICATIONS



### Model/Weight

See Additional Dimensions on Page 2.

\*Intended for indoor use only

### Dimensions

Seat Height	18.3"
Seat Back Height	34"
Seat Width	17"
Table Height	31"

## DETAILS

### Finishes

See Design Guide for finish options.

\*Due to differences in monitors, printers and materials, actual product colors may vary. Color chips are available for more accurate depiction of color.

### Options

**ADA:** ADA-compliant version with 30" x 72" x 1 1/2" laminate top. ADA-compliant version with 30" x 72" x 1 1/4" stainless steel inlay top.

**Frames:** Tamper-resistant glides, or bolt down.

**Seats:** Swivel seats, or fixed non-swivel seats.

### Assembly

Refer to manufacturer's instructions for assembly.

### Fabrication & Material


**Base Frame:** Two angled, rectangle tubes of 3" x 1 1/2" support the top and are fully welded to 3" x 1 1/2" rectangle tube and 2" square tube "H" frame structures that rest on the floor, providing support and attachment point to the seats. The top of each angled member is fully welded to a 10 gauge, 7" x 17" steel plate with reinforced gussets for mounting the laminate top. A 13.4" x 15.8" seat support plate of 10 gauge steel is securely attached to a reinforced heavy-duty swivel mechanism, which in turn attaches securely to a 9" diameter steel mounting plate. The bottom of this plate is welded to a 2" square tube with a mounting-plate inset. For free-standing applications, the inset is threaded to accommodate a tamper-resistant, skid-resistant adjustable glide with a 1/2" diameter stem. For bolt-down application, the inset has a hole for the fully enclosed tamper-resistant bolt-down system. 14 gauge steel, 2" square tubing.

**Laminate Top:** Premium M3 Grade, 45 lb. density particle board table top core is sandwiched between 1/8" thick hardboard and faced with special 0.05" thick high pressure laminate for superior quality and long term durability. Molded edge is radiused for safety and comfort, pressure fused to the top, rendering it firmly attached and highly sanitary. Embedded T-nuts secure top to base with tight steel to steel connection for maximum long term reliability. Robust 1.5" thick edge profile.

**Stainless Steel Inlay Top:** Durable type 304 stainless steel surface sealed with a specially formulated, highly durable Slammer Stone edge. Edges are radiused for safety and pressure fused to the top, rendering it firmly attached and highly sanitary. 1/4" thick edge profile.

**Seat Swivel Mechanism:** 12 gauge steel, powder coated with 60° angle allowing rotation.

**Seats:** Smooth, non-absorbent surface is easy to clean. Molded-in threaded steel inserts provide for tamper-resistant, "steel-to-steel" attachment to reinforced seat support plate. One-piece rotationally molded, specially formulated, high-impact polyethylene with ultraviolet stabilizers (to reduce fading.) Chemically resistant to blood, vinegar, urine, feces, salt solution and chlorine solution. Premium TruColor™ polymer is fully compounded for superior color consistency and durability. Made in the U.S.A.



## TESTING

### Performance Test Standards

Product tested to 1,000 lb static load

### Environmental Test Standards

- GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG
- Complies with Healthier Hospitals guidelines

## ADDITIONAL DIMENSIONS

Models	Top Dimensions	Weights	Other Dimensions	
O43048	(30" x 48")	220 lbs	Seat Height	18.3"
O43072	(30" x 72")	280 lbs	Seat Back Height	34"
			Seat Width	17"
			Table Height	31"

### Installation

Fasten frames to the floor with concealed concrete expansion anchors included with the bolt-down option. No installation required on free-standing models.

### Warranty

10 year limited replacement warranty. Intended as an indoor product.

### Maintenance

Laminate Tops: For routine and regular cleaning maintenance, Norix® recommends the use of Simple Green® or an equivalent cleaning product.

Stainless Steel Inlay Tops and Legs: When cleaning stainless steel, Norix® recommends the use of a cleaner made especially for stainless steel products.

Seats: For routine and regular cleaning maintenance, Norix® recommends the use of Simple Green® or an equivalent cleaning product. This product is bleach/water solution cleanable and suitable for use with hospital-grade disinfectants (such as Virex®, Wexcide® or Oxivir Five 16®) per manufacturers' instructions.