

Titan Safety Rail Assembly Instructions

Model Number TNT0550-00_T & TN1290-0000_T



Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List (KHAKI)					Parts List (EBONY)			
ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION	
Α	1	030-11X-XX	Safety Rail, Titan Open Style	Α	1	030-11X-XX	Safety Rail, Titan Open Style	
В	2	021-081	Screw, Machine, 5/16"-18 x 1"L, BH, Pin in Torx	В	2	021-074	Screw, Machine, 5/16-18 x 1"L, BH TR Torx, Black Oxide	
С	2	025-010	Nut, Hex, 5-16-18 Steel, Zinc	С	2	025-010	Nut, Hex, 5-16-18 Steel, Zinc	
D	2	025-011	Washer, Lock, 5/16" Zinc	D	2	025-030	Washer, Lock, 5/16", Black Oxide	
Е	2	026-006	Washer, Flat 11/32 ID X 3/4 OD x .050 18-8 SST	Е	2	025-031	Washer, Flat 11/32 ID X 5/8 OD x .083 Thick Black Oxide	
F	1	071-002	Pin in Torx Bit, T-40	F	1	071-002	Pin in Torx Bit, T-40	

Mounting the Safety Rail to a Frame Style Bed with Pre-Drilled Holes.

Tools Needed
Variable Speed Drill
5/8" Wrench

Step 1: Place Safety Rail (A) in desired position.

Step 2: Assemble the Safety Rail to the bed using (2) 5/16" Screws (B), (2) 5/16" Lock Washers (D), 11/32 ID Flat Washers (E) and (2) 5/16" Nuts (C).

Step 3: Tighten hardware securely.

