

## SPECIFICATIONS



### Model

PRD802 - Wardrobe with SafeDoor®

### Weight

Total Weight: 168 lbs

Wardrobe Weight: 160 lbs

SafeDoor® Weight: 8 lbs

Note: Dimensional tolerances are +1% due to manufacturing process.

### Wardrobe Dimensions

Overall Length 24"

Overall Width 24"

Overall Height 78"

### SafeDoor® Dimensions

Overall Thickness 1.5"

Overall Width 24"

Overall Height 67"

\*Intended for indoor use only



## DETAILS

### Wardrobe Colors

See Design Guide for finish options.

\*Proprietary TruGrain™ aesthetic provides authentic texture and gradation that replicates natural wood. Variations in color and finish vary from product to product and lot to lot, just like natural wood. Due to differences in monitors, printers and materials, actual product colors may vary.

### SafeDoor® Colors

- Harvest wardrobe come with Harvest SafeDoor®.
- Java and Biscotti wardrobes come with Java SafeDoor®.



Harvest



Java

### Options

Left or Right hinge

\*Must specify at time of order.

### Patents

Patents Pending

### Warranty

Wardrobe: 10 year limited replacement warranty.

SafeDoor®: 5 year limited replacement warranty.

### Fabrication & Material

Wardrobe: One-piece, 100% seamless, specially formulated polymer construction is structurally reinforced for superior durability, impact resistance and security. Rounded edges for added safety. Each piece is uniquely fashioned with proprietary TruGrain™ polymer formulation to replicate natural wood, and deliver a residential, non-institutional appearance. The seamless, one-piece construction delivers long-term, maintenance-free performance superior to wood in infection-control, fluid, tamper, infestation and contraband resistance. Contains a minimum of 30% recycled content.

SafeDoor®: This unique door design hangs with magnetic nylon hinges that attach to the Prodigy® Wardrobe, but collapse with just 10 pounds of force mitigating ligature risk. The high-quality vinyl material is RF welded over high-density polyurethane foam to withstand abuse. SafeDoor® is chemically resistant to bodily fluids and easy to clean. Made in the U.S.A.

### Installation

Proprietary ligature resistant floor and wall anchoring system with concealed hardware (the anchoring mechanisms are included, the anchoring hardware is NOT included). Please consult contractor or facility management as necessary. Security caulk may be applied to the perimeter after anchoring. Optional Norix® Authorized Installation services reinforce Limited Warranty.

### Warning

Normal Neodymium magnets will lose their magnetic properties if heated above 175°F (80° C). The strong magnetic fields of neodymium magnets can damage items such as television, computer monitors, credit cards, bank cards, computers, diskettes and other data carriers, video tapes, mechanical watches, hearing aids, loud speakers and VCRs. Pace-makers may be damaged or switch to "Test Mode" in the presence of a strong magnetic force, if a pace-maker or other electrical body implant is in use, keep a minimum of 3 feet distance. Under no circumstances should you try to cut, saw or drill the Neodymium magnets.

## TESTING

### Environmental Test Standards

- GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG

### Flammability Test Standards

- State of California, Technical Bulletin No. 133, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- State of California, Technical Bulletin No. 117, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- State of California, Technical Bulletin No. 116, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- ASTM E1537 Test Method for Fire testing of Real Scale Upholstered Furniture Items
- NFPA 261 Cigarette Ignition Resistance of Upholstered Furniture

## CLEANING & MAINTENANCE

Wardrobe: For routine and regular cleaning, Norix® recommends the use of Simple Green® or an equivalent cleaning product with a soft damp cloth. Prodigy® products are suitable for use with hospital-grade disinfectants (such as Virex®, Wexcide® or Oxivir Five 16®) per manufacturers' instructions.

SafeDoor®: Use Simple Green® hospital-grade cleaner or bleach & water solution on the entire door. Completely rinse with clean water (do not submerge) & wipe with soft damp cloth. Do not use a brush as that may scuff the image.