

Prodigy® Wardrobe with SafeDoor®



Model	PRD802
	168 lbs / 76.2 kg (Total)
Weight	160 lbs / 72.6 kg (Wardrobe)
	8 lbs / 3.6 kg (SafeDoor)

Wardrobe Dimensions	in	cm
Overall Length	24"	61
Overall Width	24"	61
Overall Height	78"	198.1
SafeDoor® Dimensions	in	cm
Overall Thickness	1.5"	3.8
Overall Width	24"	61
Overall Height	67"	170.2

Finishes

See Design Guide for finish options.

SafeDoor® Colors



Harvest Biscotti Java

Options

- Left or Right hinge

*Must specify at time of order.

Patents

Patents Pending

*Intended for indoor use only

Fabrication & Material

Wardrobe: One-piece, 100% seamless, specially formulated polymer construction is structurally reinforced for superior durability, impact resistance and security. Rounded edges for added safety. Each piece is uniquely fashioned with proprietary TruGrain™ polymer formulation to replicate natural wood, and deliver a residential, non-institutional appearance. The seamless, one-piece construction delivers long-term, maintenance-free performance superior to wood in infection-control, fluid, tamper, infestation and contraband resistance. Contains a minimum of 30% recycled content.

SafeDoor®: This unique door design hangs with magnetic nylon hinges that attach to the Prodigy® Wardrobe, but collapse with just 10 lbs (4.5 kg) of force mitigating ligature risk. The high-quality vinyl material is RF welded over high-density polyurethane foam to withstand abuse. SafeDoor® is chemically resistant to bodily fluids and easy to clean. Made in the U.S.A.

Warranty

Wardrobe: 10 year limited replacement warranty.

SafeDoor®: 5 year limited replacement warranty.

Maintenance

Wardrobe: For routine and regular cleaning, Norix® recommends the use of Simple Green® or an equivalent cleaning product with a soft damp cloth. Prodigy® products are suitable for use with hospital-grade disinfectants (such as Virex®, Wexcide® or Oxivir Five 16®) per manufacturers' instructions.

SafeDoor®: Use Simple Green® hospital-grade cleaner or bleach & water solution on the entire door. Completely rinse with clean water (do not submerge) & wipe with soft damp cloth. Do not use a brush as that may scuff the image.

Installation

See page 2.

Environmental Test Standards

- GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG

Flammability Test Standards

- State of California, Technical Bulletin No. 133, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- State of California, Technical Bulletin No. 117, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- State of California, Technical Bulletin No. 116, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- ASTM E1537 Test Method for Fire testing of Real Scale Upholstered Furniture Items
- NFPA 261 Cigarette Ignition Resistance of Upholstered Furniture



Installation

Proprietary ligature resistant floor and wall anchoring system with concealed hardware (the anchoring mechanisms are included, the anchoring hardware is NOT included). Please consult contractor or facility management as necessary. Tamper-resistant non-removable steel encased floor glides are included and may be field installed. Security caulk may be applied to the perimeter after anchoring.

**Normal Neodymium magnets will lose their magnetic properties if heated above 175°F (80° C). The strong magnetic fields of neodymium magnets can damage items such as television, computer monitors, credit cards, bank cards, computers, diskettes and other data carriers, video tapes, mechanical watches, hearing aids, loud speakers and VCRs. Pace-makers may be damaged or switch to "Test Mode" in the presence of a strong magnetic force, if a pace-maker or other electrical body implant is in use, keep a minimum of 3 feet (0.9 m) distance. Under no circumstances should you try to cut, saw or drill the Neodymium magnets.*