# Attenda<sup>®</sup> Platform Bed





Model	ATN101
Weight	110 - 115 lbs / 49.9 - 52.2 kg

Dimensions	in	cm
Overall Length	84″	213.4
Overall Width	40″	101.6
Height	15.5″	39.4
Bed Deck Length	82″	208.3
Bed Deck Width	38″	96.5

Note: Dimensional tolerances are +1% due to manufacturing process.

# Mattress Size

38"x82" (96.5x208.3 cm)

# **Finishes**

See Design Guide for finish options.

# **Options**

- **ATN101B**: Free-standing Bed with Fully Enclosed Bottom
- ATN103: No Mounting Holes
- ATN103B: Free-standing Bed with Fully Enclosed Bottom and no Mounting Holes

## Accessories

- Removable Restraint Rings
- Enclosure Kit
- ATN102-K: Riser
- ATN110: Headboard
- ATN-G103: Glides

#### Assembly

None Required.

\*Intended for indoor use only



## **Fabrication & Material**

Slightly textured maintenance free surface allows for easy cleaning. Rotationally molded, ligature resistant, specially formulated, high-impact polyethylene with ultraviolet light stabilizers (to reduce fading). Chemically resistant to blood, vinegar, urine, feces, salt solution and chlorine solution. Anti-ligature design with no internal openings. Premium TruColor™ polymer is fully compounded for superior color consistency and durability. Unit is filled with rigid polyurethane foam for increased durability and sound absorption. Made in the U.S.A.

## Warranty

10 year limited replacement warranty.

Norix recommends products placed in storage prior to installation should be held in a climate controlled area similar to the room where the product will be used. Norix also recommends that any Attenda® products shipped via ocean container maintain a temperature of 70-75°F (21-24°C) with a Relative Humidity of 35%.

## Maintenance

For routine and regular cleaning maintenance, Norix recommends the use of Simple Green® or an equivalent cleaning product. Attenda® products are bleach/ water solution cleanable and suitable for use with hospital-grade disinfectants (such as Virex®, Wexcide® or Oxivir Five 16®) per manufacturers' instructions. Norix recommends inspecting fasteners after each use of the restraints, along with regular monthly inspections. Bolt-down fasteners should be tight with no gaps larger than ¼6" (0.2 cm) between the bottom of the bed and the floor. There should be no visible cracks in the caulk.

# Installation

Wedge anchors and %" (0.95 cm) bolts required for permanently attaching to the floor. Anchors and bolts not supplied by Norix. Groove along underside edge for caulk application (caulk not supplied by Norix).

## Patents

This product may be covered by US Patent Nos. US 8,007,059 B2 and US 10,507,150 B2.

## **Performance Test Standards**

• Product tested to 1,000 lbs (453.6 kg) static load.

# **Environmental Test Standards**

• GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG.

## **Flammability Test Standards**

- State of California, Technical Bulletin No. 133, Flammability Test Procedurefor Seating Furniture for Use in Public Occupancies
- State of California, Technical Bulletin No. 117, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- UL1056 Fire Test of Upholstered Furniture
- ASTM E1537 Test Method for Fire Testing of Real Scale Upholstered Furniture Items
- NFPA 261 Cigarette Ignition Resistance of Upholstered Furniture