SPECIFICATIONS

DETAILS Finishes

Options

Assembly



See Design Guide for finish options.

for more accurate depiction of color.

on Unit (VFB0-1), Cuff Rings

instructions for assembly.

VersaFrame[™] ships flat-packed and

*Due to differences in monitors, printers and materials,

actual product colors may vary. Color chips are available

Non-Removable Glides, Bolt-Down Kit, Add

requires assembly. Refer to manufacturer's

Models	Width	Weight	Seat Height	Seat Width	Seat Depth	Overall Height	Overall Depth	Arm Height
VFB1-1	23"	45 lbs	18"	17"	16"	31.5"	25"	24"
VFB0-1 (Add On Unit)	21"	37 lbs						

*Intended for indoor use only



NORIX

Fabrication & Material

<u>Base Frame</u>: Square tube steel, bent and welded to provide modular, in-line seating. Flat steel plate welded to the frame at each seat location to provide strength, support, and a mounting platform on which the seat is attached. 16 gauge steel tube with 14 gauge steel seat plates with 1/4" bend.

Seats: One-piece seat and back. Smooth maintenance free surface allows for easy cleaning. Molded-in threaded steel inserts provide for tamper resistant attachment to base frame. Rotationally molded, specially formulated, high-impact polyethylene with ultraviolet light stabilizers (to reduce fading). Chemically resistant to blood, vinegar, urine, feces, salt solution and chlorine solution. Premium TruColor[™] polymer is fully compounded for superior color consistency and durability.

Installation

For bolt-down application, fasten to floor. Floor mounting hardware included.

Warranty

10 year limited replacement warranty

Maintenance

<u>Frame:</u> Norix recommends the use of soap and water for both the regular cleaning maintenance and deep-scrub cleaning of powder coated steel.

<u>Seats</u>: For routine and regular cleaning maintenance, Norix recommends the use of Simple Green[®] or an equivalent cleaning product. This product is bleach/water solution cleanable and suitable for use with hospital-grade disinfectants (such as Virex[®], Wexcide[®] or Oxivir Five 16[®]) per manufacturers' instructions.

TESTING

Performance Test Standards

- Product tested to 1,000 lb static load
- Product dynamic drop tested to a relative impact force of two times ANSI/BIFMAX 5.4 15.4.2012 (250 lbs. from 18").

Environmental Test Standards

GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG.

Flammability Test Standards

Compliant with the following flammability standards:

- State of California, Technical Bulletin No. 133, Flammability Test Procedure for Seating Furniture for Use in Public Occupancies
- UL1056 Fire Test of Upholstered Furniture
- ASTM E1537 Test Method for Fire Testing of Real Scale Upholstered Furniture Items
- NFPA 261 Cigarette Ignition Resistance of Upholstered Furniture

NORIX.COM



When Submitting a Quote Online

HOW TO ORDER -

Step 1 - Choose between single seat or multiple seats.

- Step 2 (If multiple seats are selected) type in total number of seats in tandem.
- Step 3 Select seat color.
- Step 4 Choose between bolt down or glide.
- Step 5 Option to add Cuff Ring to single seat or Cuff Rings to all seats.
- Step 6 Type in total quantity of tandem units.

Step 7 - Submit new request online for different seat color or different tandem quantity.



1 Seat



Add-On Unit



1 Seat, 1 Add-On Unit



1 Seat, 2 Add-On Units



1 Seat, 3 Add-On Units

